

# Operating and maintenance instruction

---

Swivel Joint 90° f/f 1/4" 2.0 Imp (6200 bar / 90,000 psi)



Operating and maintenance instruction

ALLFI AG - Riedenmatt 1 – CH-6370 Stans  
Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10  
E-Mail: [info@allfi.com](mailto:info@allfi.com) - <http://www.allfi.com>

July 2022

**Scope of application**

The present operating and maintenance instruction is valid for Swivel Joints 2.0 (6200 bar / 90,000 psi).

- 921600-I-P - Swivel Joint 90°f/f 1/4" 2.0 Imp

## Table of contents

1	General .....	4
1.1	Information on use of the operation and maintenance instruction .....	4
1.2	Scope of delivery .....	4
1.3	Warranty claim .....	4
1.4	Disclaimer .....	4
2	Security .....	5
2.1	Declaration of symbols .....	5
2.2	General warning notes .....	5
2.3	Intended use .....	6
2.4	Inadmissible usage .....	7
2.5	Residual risks .....	7
2.6	Safety installations .....	8
2.7	Personal protection equipment .....	8
2.8	Qualification of the staff .....	8
3	Structure and function .....	9
3.1	Structure .....	9
3.2	Function .....	10
3.3	Accessories .....	10
4	General technical data .....	11
5	Installation and commissioning .....	12
5.1	Fixing the swivel joint to the machine .....	13
5.2	Flush the swivel joint .....	14
6	Deinstallation .....	14
7	Maintenance, Service and Repair .....	15
7.1	Regular maintenance .....	15
7.2	Preventive maintenance .....	15
7.3	Replace HP-Seal .....	16
7.4	Replace cover .....	17
7.5	Replace bearing and if necessary also shaft .....	18
8	Faults and Troubleshooting .....	19
8.1	Leakage of the Swivel Joint .....	19
8.2	Further troubleshooting .....	20
9	Recycling .....	20

Appendix A – Technical drawing and parts list (shipped with the product)

## 1 General

### 1.1 Information on use of the operation and maintenance instruction

This operation and maintenance instruction is a key part of the product. The information in this manual is mandatory and must be read and understood by all the persons before operating with the Swivel Joint. The manual must be stored in distance as well as always accessible to the persons, working with the Swivel Joint.

If you have any questions regarding the contents of this manual, please contact the manufacturer directly.

ALLFI AG - Riedenmatt 1 – CH-6370 Stans  
Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10  
E-Mail: [info@allfi.com](mailto:info@allfi.com) - <http://www.allfi.com>

### 1.2 Scope of delivery

The individual parts contained in the shipment can be gathered from the set list in the appendix A (technical drawing and part list). Upon receipt, the shipment has to be checked of integrity. Possible detected defectives must be reported immediately to the manufacturer.

### 1.3 Warranty claim

The ALLFI AG grants warranty for the shipped parts as followed:

- Material and manufacturer faults of 12 months from date of delivery or
- Defects within the first 2000 hours of operation

Following spare parts are excluded from the warranty:

- Pressure Plate
- HP-Seal
- Shaft
- Bearing

### 1.4 Disclaimer

ALLFI AG refuses any claims of liability (material damages, physical injury, as well as disruption of operation), that are a result of disregarding this operating and maintenance instruction.

For example, the damage because of:

- Inadmissible application of the Swivel Joint
- Defective maintenance
- The disregard of operation instructions
- Chemical and electrolytical influences
- Use of parts, spare parts or accessory from a third-party manufacturer
- Arbitrary modifications
- Not or insufficiently trained staff

The disregard of all these instructions happens on exclusive risk and exclusive responsibility of the client. The ALLFI AG is not liable for any production downtimes.

## 2 Security

### 2.1 Declaration of symbols

This operating and maintenance instruction manual contains important notes and symbols, which are to be considered and followed. These include:



#### • DANGER

**Danger emphasizes operating and service procedures that if not avoided, may lead to death or serious personal injuries.**



#### • WARNING

**Warnings emphasize operating or service procedures, or conditions that can result in serious personal injury or death.**



#### • CAUTION

**Cautions emphasize operating or service procedures, or conditions that can result in equipment damage or impairment of system operation. If not avoided, light or medium body injuries could be the consequence.**

#### NOTE

**Notes provide additional information that can expedite or improve operating or service procedures.**



Danger symbol without key word: Additional notes

### 2.2 General warning notes

Using of the Swivel Joint, the following warnings are to be considered.



The specified warnings are not only restricted to the operation with the maximal permissible operating pressure of 6200 bar / 90,000 psi. They are also valid on work with reduced operation pressures!

**• DANGER****Danger of cutting of extremities on contact with waterjet**

The contact with the high kinetic energy performing waterjet can have the consequence of cutting of extremities or lead to other injuries.

**Therefore:**

- Operate the machine only, when nobody stands in the danger zone of the waterjet.
- Never touch the waterjet, not even with personal protective equipment.
- Always maintain a sufficient safety distance from the swivel joint when it is pressurized.



Any injuries in connection with the waterjet, alarm the emergency doctor immediately.

**• CAUTION****Danger of breathing difficulties and irritation of the skin and eyes by released solid particles or dust.**

During machining of certain material, solid particles and dust may float in the air, which could cause breathing difficulties and irritations to the skin and eyes.

**Therefore:**

- Ensure the proper ventilation of the room surrounding the machinery.
- Ensure to wear the personal protective equipment (protection glasses, breathing mask, gloves, ...)



Additionally, the rules and regulations of the working place are to be followed to prevent injuries!



## 2.3 Intended use

The Swivel Joint is designed for the transmission of rotary movements. The swivel joint must be firmly attached to the machine. Only pure water may be used as working fluid. The technical limit values must always be observed.

## 2.4 Inadmissible usage

Inadmissible usage of the Swivel Joint includes:

- The usage of all other fluids other than water
- The addition of other substances to the water
- Closure of the pressure relief holes
- Excessive application of the Swivel Joint 2.0
- Exceeding permitted limits
- Operating the Swivel Joint with demounted or disabled technical protection
- Transmission of axial and/or radial forces
- The use in the food or pharmaceutical sector

Likewise, all other uses of the Swivel Joint deviating from the intended use are not permitted. All questions should be addressed directly to the manufacturer.

ALLFI AG - Riedenmatt 1 – CH-6370 Stans

Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10

E-Mail: [info@allfi.com](mailto:info@allfi.com) - <http://www.allfi.com>

## 2.5 Residual risks

The manufacturer and/or operator of the machine where the Swivel Joint 2.0 is built in, has taken every precautionary measure possible to reduce residual risks, as far as possible reasonably practically.

Operation phase	Damage	Danger	Reason	(possible) measures
Operation	Physical injuries	Liquids leaking under high pressure (e.g. at pressure relief holes)	Ignoring the torque	Follow the torque
			Damaged sealing surfaces	Regular supervision
			Busted/Cracked connections and high-pressure components as a result of defects	Protective wall as a technical protective measure
		Flying fragments	Ignoring the torque	Follow the torque
			Damaged sealing surfaces	Regular supervision
			Busted/Cracked connections and high-pressure components as a result of defects	Protective wall as a technical protective measure

## 2.6 Safety installations

The manufacturer or the operator of the full machine, which the Swivel Joint is built in, has ensured the following safety arrangements:


- Safety devices to prevent flying fragments or liquids leaking under high pressure
- Emergency stoppage to immediately shut down the operating machine. This emergency stoppage is an integral part of the system that automatically activates in case of the failure of high-pressure components or massive operating errors, alternatively it may be manually activated by the operator.



Danger for the operator will arise if safety protections are not functionally, not followed or evaded anytime. The operator has to ensure the functionality of the safety protections anytime.

## 2.7 Personal protection equipment

The operator must offer his staff following protection equipment while he's working:



Ear protector against:

- Noise emissions

Wear protection glasses against:

- Fluids and dust particles
- Flying fragments

Hand guards against:

- Sharp edges of components
- Intrusion of micro particles into the skin

Inhalation protection against:

- Dust particles, micro particles and spray mist


## 2.8 Qualification of the staff

The Swivel Joint may only be operated and maintained by certified, trained staff.

### 3 Structure and function

#### 3.1 Structure

The Swivel Joint can be rotated with very low resistance even at a maximum pressure of 6200 bar / 90,000 psi.





Legend:

1. Cover 90° 2.0 Imp
2. Pressure Plate 2.0
3. HP-Seal 2.0
4. Shaft for Swivel Joint f 2.0
5. Bearing for Swivel Joint
6. Housing f 2.0
7. O-Ring
8. O-Ring
9. Sleeve M10 - 5/8"
10. Gland Nut 1/4"
11. Collar 1/4"



### 3.2 Function

The swivel joint transmits rotary motion of 1/4" high pressure lines up to a pressure of 6200 bar / 90,000 psi. The swivel joint cannot transmit forces. The maximum allowable operating pressure of water is 6200 bar / 90,000 psi.

### 3.3 Accessories

		
Article:	Torque wrench	Spanner
Article no:	883000	AF 11/16" – 000629 AF 32 – 000503 only for 9/16"
Function:	Tightens screws with a specific torque	

		
Article:	Disassembly Tool	Molykote DX Paste
Article no:	910078	051055
Function:	Disassembly HP Seal from Swivel Joint	Greasing screw connections and metallic contact areas

		
Article:	Spare Part-Set	Socket Wrench
Article no:	890052-P	000631
Consist of:	HP-Seal, Pressure Plate, Shaft, Needle bearing, O-Rings	Special tool for Spare Part-Set

## 4 General technical data

Maximal working pressure:	6200 bar / 90,000 psi
Maximum recommended flow rate:	3 L/min / 0.8 gal/min
Connection tube diameter:	HP Tube 1/4"
Nominal diameter DN	1.2 mm
Flow Coefficient Kv/ Cv for water	0.8 l/min / 0.056 gallon/min
Weight:	approx. 580g
Maximal working temperature:	50 °C
Maximal stocking temperature:	60 °C

Requested water quality:

Water parameter	Unit	Value
Electrical Conductivity	µS / cm	100 – 450
PH-value	-	7.0 - 8.5
Total hardness	°dH	2.0 - 10.0
Carbonate hardness (acid capacity pH 4.3)	°dH	2.0 - 10.0
Degree of alkalinity pH 8.2	mmol / l	0 - 0.25
Chloride	mg / l	≤ 50
Iron	mg / l	≤ 0.2
Manganese	mg / l	≤ 0.05
Copper	mg / l	≤ 2.0
Silicate	mg / l	≤ 5.0
(Filtrate-) solid content	mg / l	≤ 350

Technical data as dimensions can be found in the technical drawing in appendix A.

## 5 Installation and commissioning

### General installation tip:

- Absolute cleanliness of the pipes is important before connection.
- Follow the steps below for installation.
- During startup and after inspection or maintenance, check the water tightness of the pneumatic valve.

### • WARNING

**Risk of injury: It is forbidden to close the pressure relief holes.**

By closing the pressure relief holes, the Swivel Joint or parts of it may explode.

**Therefore:** Never close or cover any pressure relief holes.

**Positions of the pressure relief holes (red arrows):**



### NOTE

#### Material damage as a result of pitting

Not or insufficient greased threads or contact areas can pit.

**Therefore:**

Always grease threads and metallic contact areas with DX-Paste (Article no. 051055). Check appendix A for additional information.

**NOTE****Material damage or leakage as a result of fouling**

Fouling components, especially at threads, can lead to leakages and damage.

**Therefore:**

Pay attention to the cleanliness of the components while maintaining.

**NOTE****Material damage as a result of leakages**


Constant leakage may damage the product.

**Therefore:**

Immediately eliminate leakages (see chapter 8 „Faults and Troubleshooting“).




## 5.1 Fixing the swivel joint to the machine

The swivel joint is attached to the machine with the four M5 threads. Further fastening options must be discussed with the manufacturer.



During installation, ensure that none of the pressure relief holes are closed!

Make sure that the HP tubes are connected stress-free, i.e. do not exert any forces on the shaft.

	1. Slide the gland nut over the HP tube
	2. Screw the collar on the HP tube (left-handed thread). There must be 1 or 2 convolutions visible between the conus and the pressure ring.
	3. Connect the high-pressure lines to the Swivel Joint. (Torque see appendix A)


5.2 Flush the swivel joint

Flush swivel joint with water ( $p \leq 500$  bar) for 5 to 10 seconds.

6 Deinstallation



Before uninstalling the Swivel Joint, release the pressure of the high-pressure pipes and protect them against unexpected re-pressurization

	<p>Remove high pressure line and its components.</p> <p>Remove Swivel Joint from machine.</p>
---	---

## 7 Maintenance, Service and Repair



Before uninstalling the Swivel Joint, release the pressure of the high-pressure pipes and protect them against unexpected re-pressurization

The swivel joint must be removed from the machine for maintenance, service and repair work in accordance with Chapter 6.

All maintenance, service and repair work not listed in this chapter must be carried out by the manufacturer.

### NOTE

#### Material damage or leakage as a result of fouling

Dirty components, especially considering the threads, may lead to leakages and damage of the Swivel Joint.

#### Therefore:

Ensure a proper cleaning of the components.

### NOTE

#### Property damage as a result of pitting

Threads that are not greased or insufficiently greased may pit.

#### Therefore:

Always grease threads and metallic contact areas with DX-Paste (Article no. 051055). Check appendix A for additional information.

### 7.1 Regular maintenance

What	By whom	When
Check tightness	Operator	Continuous
Rotary resistor	Operator	Periodically

### 7.2 Preventive maintenance





Every 25'000 revolutions or rotational movements: Replace seal and pressure plate, after 1 year at the latest.



Every 75'000 revolutions or rotational movements: Maintenance at ALLFI, replace bearing and shaft, after 3 years at the latest.

Replace swivel joint after 20'000 cycles: Pressure increase from 0 to > 3500 bar (pump start).

### 7.3 Replace HP-Seal



Remove the swivel joint from the machine according to chapter 6.




1		<ol style="list-style-type: none"> <li>1. Clamp the swivel joint on the cover in a vice at the wrench size 30mm. <b>Attention!</b> Use protective jaws.</li> <li>2. Loosen the housing by one turn with an open-end wrench SW 32.</li> </ol>
2		<ol style="list-style-type: none"> <li>1. Turn the swivel joint around and clamp it in the vise on the SW 32 of the housing.</li> <li>2. Unscrew cover.</li> <li>3. Check the shaft in the area of the seal for wear. If this is damaged, have the swivel joint repaired by an ALLFI service technician.</li> </ol>
3		<ol style="list-style-type: none"> <li>1. Remove the seal with the Disassembly Tool (910078).</li> <li>2. Clean cover</li> </ol>
4		<ol style="list-style-type: none"> <li>1. Clean housing and pressure plate</li> <li>2. Grease the sealing surface according to appendix A.</li> <li>3. Push the new HP seal over the shaft until it stops.</li> </ol>

5		<ol style="list-style-type: none"> <li>1. Grease thread according to appendix A.</li> <li>2. Screw the cover onto the housing by hand.</li> </ol>
6		<ol style="list-style-type: none"> <li>1. Turn the swivel joint around and clamp it in the vise on the SW 30 of the cover.</li> <li>2. Tighten with torque wrench at SW 32. (Torque see Appendix A).</li> <li>3. Fix the swivel joint in the machine according to chapter 5.1 and flush according to chapter 5.2.</li> <li>4. Check the water tightness of the Swivel Joint</li> </ol>

## 7.4 Replace cover

Remove the swivel joint from the machine according to chapter 6.

1		<ol style="list-style-type: none"> <li>1. Clamp the swivel joint on the cover in a vice at the wrench size 30mm. <b>Attention!</b> Use protective jaws.</li> <li>2. Loosen the housing by one turn with an open-end wrench SW 32.</li> </ol>
2		<ol style="list-style-type: none"> <li>1. Turn the swivel joint around and clamp it in the vise on the SW 32 of the housing.</li> <li>2. Unscrew cover.</li> <li>3. Check the shaft in the area of the seal for wear. If this is damaged, have the swivel joint repaired by an ALLFI service technician.</li> </ol>

3		<ol style="list-style-type: none"> <li>1. Dispose of the old cover together with the seal.</li> <li>2. Clean housing and pressure plate</li> <li>3. Grease the sealing surface according to appendix A.</li> <li>4. Push the new HP seal over the shaft until it stops.</li> </ol>
4		<ol style="list-style-type: none"> <li>1. Grease thread according to appendix A.</li> <li>2. Screw the cover onto the housing by hand.</li> </ol>
5		<ol style="list-style-type: none"> <li>1. Turn the swivel joint around and clamp it in the vise on the SW 30 of the cover.</li> <li>2. Tighten with torque wrench at SW 32. (Torque see Appendix A).</li> <li>3. Fix the swivel joint in the machine according to chapter 5.1 and flush according to chapter 5.2.</li> <li>4. Check the water tightness of the Swivel Joint</li> </ol>

## 7.5 Replace bearing and if necessary also shaft

Please contact the manufacturer for a repair on site or at the nearest ALLFI location.

ALLFI AG - Riedenmatt 1 – CH-6370 Stans

Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10

E-Mail: [info@allfi.com](mailto:info@allfi.com) - <http://www.allfi.com>


## 8 Faults and Troubleshooting



Before uninstalling the Swivel Joint, release the pressure of the high-pressure pipes and protect them against unexpected re-pressurization

**Warning!** After any troubleshooting, check the water tightness of the Swivel Joint.

### 8.1 Leakage of the Swivel Joint



Pos. of the leakage.	Cause of the leakage	Action	Chapter
<b>1</b> HP screw connection on cover	Wrong torque of the screw connection	Check torque of screw connection	5.1
	sealing surfaces on HP tube or cover damaged	Check sealing surfaces on HP tube and cover. If parts are damaged, rework or replace	
	Cover broken	Replace cover 90°	7.4
<b>2</b> HP screw connection on shaft/sleeve	Wrong torque of the screw connection	Check torque of screw connection	5.1
	sealing surfaces on HP tube or cover damaged	Check sealing surfaces on HP tube and shaft. If parts are damaged, rework or replace	
<b>3</b> Sealing point HP-Seal	HP Seal untighten.	Replace HP Seal	7.3
	Shaft or pressure plate damaged	Replace shaft and pressure plate (only by ALLFI service technicians)	7.5
	sealing surfaces on cover or pressure plate damaged	Replace cover and pressure plate	7.4
	Water pressure too high	Consider application limits	4

## 8.2 Further troubleshooting

Error	Cause	Action	Chapter
Swivel Joint clogged	Pipe dirty	Disassemble, clean and reassemble the swivel joint	7.2 - 7.3
		Use filters	
Swivel Joint is jammed	Bearing defective	Replace bearing (only by ALLFI service technicians)	7.5

## 9 Recycling

The Swivel Joint is made of metal and plastic. All the metal parts can be recycled. The plastic parts are to be professionally recycled as per local specifications.