

Operating and maintenance instruction

Pneumatic Valve 2.0 (4'150 bar / 60'000 psi) Normally closed and normally open



Operating and maintenance instruction

ALLFI AG - Riedenmatt 1 - CH-6370 Stans

Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10

E-Mail: info@allfi.com - http://www.allfi.com

November 2023

General



Scope of application

The present operating and maintenance instruction is valid for all pneumatic valves 2.0 (4'150 bar / 60'000 psi).

- 901070
- 901080
- 901770
- 901780
- 910070
- 910080
- 910170
- 910180
- 910270
- 910280
- 910370
- 910380
- 910470
- 910480
- 910570
- 010010
- 910580
- 910670
- 910680
- 910870
- 910880
- 910970
- 910980
- 911170
- 911180
- 912170901070-I
- 901080-I

- 901770-I
- 901780-I
- 910070-I
- 910080-I
- 910170-I
- 910180-I
- 910270-I
- 910280-I
- 910370-I
- 910380-I
- 910470-I
- 910480-I
- 910570-I
- 910580-I
- 910670-I
- 910680-I
- 910870-I
- 910880-I
- 910970-I
- 910980-I
- 911170-I
- 911180-I
- IT-910280-IIT-910480
- IT-911180-I
- UH-910480

General



Table of contents

| 1 | Gen | eral | . 4 |
|----|--------|---|-----|
| | 1.1 | Information on use of the operation and maintenance instruction | . 4 |
| | 1.2 | Scope of delivery | . 4 |
| | 1.3 | Warranty claim | . 4 |
| | 1.4 | Disclaimer | . 4 |
| 2 | Secu | ırity | . 5 |
| | 2.1 | Declaration of symbols | . 5 |
| | 2.2 | General warning notes | . 5 |
| | 2.3 | Intended use | . 6 |
| | 2.4 | Inadmissible usage | . 7 |
| | 2.5 | Residual risks | . 7 |
| | 2.6 | Safety installations | . 8 |
| | 2.7 | Personal protection equipment | . 8 |
| | 2.8 | Qualification of the staff | . 8 |
| 3 | Stru | cture and function | . 9 |
| | 3.1 | Structure | .9 |
| | 3.2 | Function | . 9 |
| | 3.3 | Accessories | 10 |
| 4 | Gen | eral technical data | 10 |
| 5 | Inst | allation and commissioning | 11 |
| | 5.1 | Flow direction | 13 |
| | 5.2 | Installation | 13 |
| 6 | Deir | nstallation | 14 |
| 7 | Mai | ntenance, Service and Repair | 14 |
| | 7.1 | Replace HP Seal | 15 |
| | 7.2 | Replace Sealing kit | 17 |
| 8 | Faul | ts and Troubleshooting | 20 |
| | 8.1 | Leakage of the pneumatic valve 2.0 | 20 |
| | 8.2 | Pneumatic valve 2.0 normally open NO | |
| | 8.3 | Pneumatic valve 2.0 normally closed | |
| 9 | | /cling | |
| 10 | Арр | endix B | 22 |
| 11 | aqA | endix C | 23 |
| 12 | | on Sensor Valves NC | |
| | - 1- 0 | | |

Appendix A – Technical drawing and parts list (shipped with the product)

Appendix B – general chart of design and article numbers normally open

Appendix C – general chart of design and article numbers normally closed



1 General

1.1 Information on use of the operation and maintenance instruction

This operation and maintenance instruction is a key part of the product. The information in this manual is mandatory and must be read and understood by all the persons before operating with the pneumatic valve 2.0. The manual must be stored in distance as well as always accessible to the persons, working with the pneumatic valve 2.0.

Should you have any questions regarding the content of the manual, please contact the manufacturer directly.

ALLFI AG - Riedenmatt 1 – CH-6370 Stans

Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10

E-Mail: info@allfi.com - http://www.allfi.com

1.2 Scope of delivery

The individual parts contained in the shipment can be gathered from the set list in the appendix A (technical drawing and part list). Upon receipt, the shipment has to be checked of integrity. Possible detected defectives must be reported immediately to the manufacturer.

1.3 Warranty claim

The ALLFI AG grants warranty for the shipped parts as followed:

- Material and manufacturer faults of 12 months from date of delivery or
- ➤ Defects within the first 2'000 hours of operation

Following spare parts are excluded from the warranty:

- Seal Kit
- Pneumatic Cylinder (must be replaced after 100'00 cycles)
- Pressure Plate
- Valve Body

1.4 Disclaimer

ALLFI AG refuses any claims of liability (material damages, physical injury, as well as disruption of operation), that are a result of disregarding this operating and maintenance instruction.

For example, the damage because of:

- > Inadmissible application of the valve
- Defective maintenance
- > The disregard of operation instructions
- Chemical and electrolytical influences
- Use of parts, spare parts or accessory from a third-party manufacturer
- Arbitrary modifications
- Not or insufficiently trained staff

The disregard of all these instructions happens on exclusive risk and exclusive responsibility of the client. The ALLFI AG is not liable for any production downtimes.



2 Security

2.1 Declaration of symbols

This operating and maintenance instruction manual contains important notes and symbols, which are to be considered and followed. These include:



A DANGER

Danger emphasizes operating and service procedures that if not avoided, may lead to death or serious personal injuries.



WARNING

Warnings emphasize operating or service procedures, or conditions that can result in serious personal injury or death.



A CAUTION

Cautions emphasize operating or service procedures, or conditions that can result in equipment damage or impairment of system operation. If not avoided, light or medium body injuries could be the consequence.

NOTE

Notes provide additional information that can expedite or improve operating or service procedures.



Danger symbol without key word: Additional notes

2.2 General warning notes

Using of the pneumatic valve 2.0, the following warnings are to be considered.



The specified warnings are not only restricted to the operation with the maximal permissible operating pressure of 4'150 bar / 60'000 psi. They are also valid on work with reduced operation pressures!



A DANGER

Danger of cutting of extremities on contact with waterjet



The contact with the high kinetic energy performing waterjet can have the consequence of cutting of extremities or lead to other injuries.


Therefore:

- > Operate the machine only when nobody stands in the danger zone of the waterjet.
- Never touch the waterjet, not even with personal protective equipment.



Any injuries in connection with the waterjet, alarm the emergency doctor immediately.

A CAUTION





During machining of certain material, solid particles and dust may float in the air, which could cause breathing difficulties and irritations to the skin and eyes.

Therefore:

- Ensure the proper ventilation of the room surrounding the machinery.
- Ensure to wear the personal protective equipment (protection glasses, breathing mask, gloves, ...)



Additionally, the rules and regulations of the working place are to be followed to prevent injuries!

2.3 Intended use

The intended use consists in:

- > operate the pneumatic valve 2.0 with air pressure
- block the water with a pressure of max. 4'150 bar / 60'000 psi (static applications)
- > the fixed installation (no hand guidance) of the pneumatic valve 2.0 on the machine
- if provisions against flying fragments or a leaking liquid with high pressure are made
- if water is used exclusively as working fluid
- > if the technical limit values are respected



2.4 Inadmissible usage

Inadmissible usage of the pneumatic valve 2.0 includes:

- ➤ The usage of all other fluids other than water
- > The addition of other substances to the water
- > Closure of the pressure relief holes
- Excessive application of the valve e.g. large fluctuations in pressure
- > Exceeding permitted limits
- > Operating the valve with demounted or disabled technical protection
- > Use the pneumatic valve as a cutting head

Likewise, all other uses of the valve deviating from the intended use are not permitted. All questions should be addressed directly to the manufacturer.

ALLFI AG - Riedenmatt 1 - CH-6370 Stans

Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10

E-Mail: info@allfi.com - http://www.allfi.com

2.5 Residual risks

The manufacturer and/or operator of the machine where the pneumatic valve 2.0 is built in, has taken every precautionary measure possible to reduce residual risks, as far as possible reasonably practicably.

| Operation phase | Damage | Danger | Reason | (possible) measures |
|-----------------|----------------------|---|---|---|
| | Physical injuries | Liquids leaking under high pressure (e.g. at pressure relief holes) | Ignoring the torque | Follow the torque |
| | | | Damaged sealing surfaces | Regular supervi- sion |
| | | | Busted/Cracked | |
| Operation | | | connections and high-pressure components as a result of defects | Protective wall as a technical protective measure |
| Срогашен | | | Ignoring the torque | Follow the torque |
| | | | Damaged sealing surfaces | Regular supervi- sion |
| | | Flying fragments | Busted/Cracked | |
| | | | connections and high-pressure components as a result of defects | Protective wall as a technical protective measure |



2.6 Safety installations

The manufacturer or the operator of the full machine, which the pneumatic valve 2.0 is built in, has ensured the following safety arrangements:

- > Safety devices to prevent flying fragments or liquids leaking under high pressure.
- Emergency stoppage to immediately shut down the operating machine. This emergency stoppage is an integral part of the system that automatically activates in case of the failure of high pressure components or massive operating errors, alternatively it may be manually activated by the operator.



Danger for the operator will arise if safety protections are not functionally, not followed or evaded anytime. The operator has to ensure the functionality of the safety protections anytime.

2.7 Personal protection equipment

The operator must offer his staff following protection equipment while he's working:



Ear protector against:

Noise emissions

Wear protection glasses against:

- > Fluids and dust particles
- > Flying fragments

Hand guards against:

- > Sharp edges of components
- > Intrusion of micro particles into the skin

Inhalation protection against:

> Dust particles, micro particles and spray mist

2.8 Qualification of the staff

The pneumatic valve 2.0 may only be operated and maintained by certified, trained staff.




3 Structure and function

3.1 Structure

The pneumatic valve 2.0 is available for 1/4", 3/8" and 9/16" tubes, as straight, angle, 3-way and 2-stem valve and the pneumatic cylinder as normally open and normally closed.

The valve is also as a manual hand valve available (check additional operation and maintenance instruction and article in the web shop.

The explosion views of the pneumatic valve 2.0 normally open and normally closed are shown below.



Legend:

- 1. Pneumatic Cylinder NO
- 2. Needle complete
- 3. Spring
- 4. Pressure Plate
- 5. HP Seal
- 6. Conical Disc
- 7. Valve Body
- 8. Collar
- 9. Gland Nut

- 1. Pneumatic Cylinder NC
- 2. Needle complete
- Spring
- 4. Pressure Plate
- 5. HP Seal
- 6. Conical Disc
- 7. Valve Body
- 8. Collar
- 9. Gland Nut

3.2 Function

The pneumatic valve 2.0 is a needle valve. The valve needle is moved by pneumatic pressure and spring force. The seal kit is replaceable by removing the pneumatic cylinder. The maximal permissible operating water pressure is 4'150 bar / 60'000 psi. The operation pneumatic pressure must be 6 -7 bar / 87 -100 psi anytime.



3.3 Accessories

| Article: | Torque wrench | Spanner | Assembling Tool |
|-------------|--|---|---|
| Article no: | 000468 | AF 17 – 000339 only for 1/4" AF 22 – 000272 only for 3/8" AF 24 – 000280 AF 32 – 000503 only for 9/16" | 912198 |
| Function: | Tightens screws with a specific torque | | Tightens pneumatic cylinder with torque wrench AF24 |

| | | Olster Street Barbara | |
|-------------|-------------------------------------|---|---------------------------------|
| Article: | Disassembly Tool | Molykote DX Paste | Mounting tool for O-ring |
| Article no: | 910078 | 051055 | 040011 |
| Function: | Disassembly HP Seal from Valve Body | Greasing screw connections and metallic contact areas | Dissassembly of Conical Disc |

4 General technical data

Maximal working pressure: 4'150 bar / 60,000 psi

Connection tube diameter: HP Tube 1/4", 3/8", 9/16"

Pneumatic pressure: 6-7 bar / 87-100 psi

Minimum valve diameter: 2.2 mm

Design: Check appendix B and C

Maximal working temperature: 50 °C

Maximal stocking temperature: 60 °C

Technical data as dimensions can be found in the technical drawing in appendix A.

Installation and commissioning



Requested water quality:

| Water parameter | Unit | Value |
|-----------------------------|----------|------------|
| Electrical Conductivity | μS / cm | 100 – 450 |
| PH-value | - | 7.0 - 8.5 |
| Total hardness | °dH | 2.0 - 10.0 |
| Carbonate hardness | °dH | 2.0 - 10.0 |
| (acid capacity pH 4.3) | | |
| Degree of alkalinity pH 8.2 | mmol / I | 0 - 0.25 |
| Chloride | mg / I | ≤ 50 |
| Iron | mg / I | ≤ 0.2 |
| Manganese | mg / I | ≤ 0.05 |
| Copper | mg / I | ≤ 2.0 |
| Silicate | mg / I | ≤ 5.0 |
| (Filtrate-) solid content | mg / I | ≤ 350 |

5 Installation and commissioning

General installation tip:

- ➤ Absolute cleanliness of the pipes is important before connection.
- > Follow the steps below for installation.
- > Before startup and after inspection or maintenance, check the water tightness of the pneumatic valve.
- > Use of a pneumatic oiler is forbidden.
- Compressed air filter with water separator must be installed. Compressed air must be dry.

NOTE

Material damage as a result of pitting

Not or insufficient greased threads or contact areas can pit.

Therefore:

Always grease threads and metallic contact areas with DX-Paste (Article no. 051055). Check appendix A for additional information.



NOTE

Material damage or leakage as a result of fouling

Fouling components, especially at threads, can lead to leakages and damage.

Therefore:

Pay attention to the cleanliness of the components while maintaining.

NOTE

Material damage as a result of leakages

Constant leakage may damage the product.

Therefore:

Immediately eliminate leakages (see chapter 8 "Faults and Troubleshooting").

WARNING

Risk of injury: It is forbidden to close the pressure relief holes.

By closing the pressure relief holes, the pneumatic valve or parts of it may explode.

Therefore: Never close or cover any pressure relief hole.

> Positions of the pressure relief holes:








TITIVO


5.1 Flow direction

The flow direction depends primarily on the pressure conditions in the connected high-pressure pipes. To achieve long service lives, port A should be subjected to as few pressure fluctuations as possible.



With frequent switching (more than one switching cycle per 5 operating hours on average), port A should be under pressure when the valve is closed. As a result, the HP seal and the valve body are subjected to static stress. The B/C connection is subjected to dynamic stress.

In the case of occasional switching (less than one switching cycle per 5 operating hours on average), the situation is the opposite since the switching cycles are less important than the pressure fluctuations in the line network.



The above information on the switching cycles are rough guide values. In case of doubt, it is recommended to contact the supplier. The same also applies to applications where both A and B/C may be under pressure when the valve is closed.

5.2 Installation



During installation, ensure that none of the pressure relief holes are closed!

Consider flow direction \rightarrow see chapter 5.1

| Slide the gland nut over the HP tube. |
|--|
| Screw the collar on the HP tube (left handed thread). There must be 1 or 2 convolutions visible between the conus and the pressure ring. |

Deinstallation





Fix pneumatic valve 2.0 with two/four screws M6 (M5 for imperial 1/4" and imperial 3/8") on the machine.

Connect the high-pressure line to the pneumatic valve 2.0 (torque see appendix A).

Connect pneumatic hose.

6 Deinstallation



Before uninstalling the pneumatic valve 2.0, release pressure from the HP tubes to avoid unexpected re-pressurizing.



Remove pneumatic hose and HP tube.

Remove the pneumatic valve 2.0 from the machine.

7 Maintenance, Service and Repair

It's not necessarily to unmount the pneumatic valve 2.0 from the machine. Usually the maintenance is easier if the HP tubes are removed and the pneumatic valve 2.0 is unmounted from the machine.

The pneumatic valve 2.0 requires little maintenance expenditure. The lifetime of the sealing, the needle and the valve body depend on the actuation frequency, the pressure and the pressure fluctuations. Preventive maintenance is not possible.

The springs of the pneumatic cylinder must be replaced every 5 years or after 1'000'000 cycles, which occurs earlier.

Once a year, all parts of the pneumatic cylinder must be checked for rust. In case of rust, replace the pneumatic cylinder.



NOTE

Material damage or leakage as a result of fouling

Dirty components, especially considering the threads, may lead to leakages and damage of the pneumatic valve 2.0.

Therefore:

Ensure a proper cleaning of the components.

NOTE

Possible damage as a result of direct transfer of the torque to the HP-tubes

Loosening or tightening the pneumatic cylinder (pos. 1 on page 10) make sure that the torque is not transmitted to the HP-tubes, as these can be damaged.

NOTE

Property damage as a result of pitting

Threads that are not greased or insufficiently greased may pit.

Therefore:

Always grease threads and metallic contact areas with DX-Paste (Article no. 051055). Check appendix A for additional information.

The following instructions are described using the pneumatic valve 2.0 straight normally open. The procedure is the same for all other types of pneumatic valves 2.0, unless otherwise noted.

7.1 Replace HP Seal



Release pressure of the HP tubes before opening to protect against repressurization.

| 1 | Disconnect pneumatic hose and HP Tubes. Remove the pneumatic valve 2.0 from the machine. |
|---|---|
| 2 | Fix it in bench vice. Attention! Use protective jaws. |



| or valve is d screw on tting. |
|--|
| nder NC |
| ylinder with 7 bar). 2.0 is now t will not be |
| der with the 98 and an 94 and re- |
| air and re- |
| nder NO |
| der with the 98 and an AF24. |
| cylinder. |
| and pres- plier. |
| isassembly |
| sk is in the red in pic- |
| a new HP plate and ed surfaces 1055. |
| sk isk red a n |



| | · · · · · · · · · · · · · · · · · · · |
|----|--|
| 8 | Press the new seal kit into the valve body. |
| | For pneumatic cylinder NC |
| 9a | Pressurize pneumatic cylinder with compressed air (6-7 bar). The pneumatic valve 2.0 is now open and the valve seat will not be damaged. Tighten the pneumatic cylinder with the assembling tool 912198 and a torque wrench (moment of force according appendix A). Remove the pneumatic hose. |
| | If the option sensor valve is used, unscrew push-in fitting and screw on the option sensor valve. |
| 9b | For pneumatic cylinder NO Tighten the pneumatic cylinder with the assembling tool 912198 and a torque wrench (moment of force according appendix A). |
| 10 | Fix pneumatic valve 2.0 on the machine. Connect the high-pressure line to the pneumatic valve 2.0 (torque see appendix A). |
| | Connect pneumatic hose. |

7.2 Replace Sealing kit



Release pressure of the HP tubes before opening to protect against repressurization.

| | Disconnect pneumatic hose and HP Tubes. Remove the pneumatic valve 2.0 from the machine. |
|--|---|
|--|---|



| 2 | Fix it in bench vice. Attention! Use protective jaws. |
|-----|--|
| 2.1 | If the option sensor valve is used, unscrew it and screw on the push- in fitting. |
| 3a | For pneumatic cylinder NC Pressurize pneumatic cylinder with compressed air (6-7 bar). The pneumatic valve 2.0 is now open and the valve seat will not be damaged. Loosen pneumatic cylinder with the assembling tool 912198 and an openend wrench AF24 and remove it. Release compressed air and remove air hose. |
| 3b | For pneumatic cylinder NO Loosen pneumatic cylinder with the assembling tool 912198 and an openend wrench AF24. Remove pneumatic cylinder. |
| 4 | Remove needle, spring and pressure plate with a plier. |
| 5 | Remove HP seal with disassembly tool 910078. |



| | | <u>'</u> |
|-----|--|--|
| 6 | | Remove valve body from bench vice Remove conical disk with Mounting tool |
| 7 | | Assemble new seal kit with a new needle complete, a new spring, a new pressure plate, a new HP seal and a new conical disk. |
| | | Grease the pressure plate and needle on the red marked surfaces with DX-Paste 051055. |
| 8 | | Screw spindle into valve body from below. |
| 9 | | Fix valve body in bench vice again. |
| 10a | | For pneumatic cylinder NC Pressurize pneumatic cylinder with compressed air (6-7 bar). The pneumatic valve 2.0 is now open and the valve seat will not be damaged. Tighten the pneumatic cylinder with the assembling tool 912198 and a torque wrench (moment of force according appendix A). Remove the pneumatic hose. If the option sensor valve is used, unscrew push-in fitting and screw on the option sensor valve. |
| 10b | | For pneumatic cylinder NO Tighten the pneumatic cylinder with the assembling tool 912198 and a torque wrench (moment of force according appendix A). |

Faults and Troubleshooting





Fix pneumatic valve 2.0 on the machine.

Connect the high-pressure line to the pneumatic valve 2.0 (torque see appendix A).

Connect pneumatic hose.

8 Faults and Troubleshooting



Before uninstalling the pneumatic valve 2.0, release pressure from the HP tubes and protect against an unexpected re-pressurizing.

Warning! After any troubleshooting, check the water tightness of the pneumatic valve 2.0.

8.1 Leakage of the pneumatic valve 2.0



| Pos. | Cause of the lockage | Action | Chapter |
|-------|---|-----------------------|---------|
| 4 | | Check moment of force | 7.1 |
| 1 | 1 HP Seal untight | Replace HP Seal | 7.1 |
| 2,3,4 | Screw connection high pressure tube not tight | Tighten Screw | 5.1 |

8.2 Pneumatic valve 2.0 normally open NO

| Error | Cause | Action | Chapter |
|----------------------------|---------------------------------------|--|---------|
| Pneumatic | Pneumatic pressure to low | Check pneumatic pressure | |
| valve 2.0 doesn't close | Debris in valve seat | Clean pneumatic valve 2.0, use HP filter | 7.1 |
| properly / com- pletely | Valve seat and/or needle cone damaged | Replace seal kit and/or replace valve body | 7.2 |

Recycling



| | Pneumatic cylinder malfunction | Pneumatic cylinder repair by manufacturer | |
|---------------------|----------------------------------|---|-----|
| | Spring malfunction | Replace seal kit | 7.2 |
| Pneumatic valve 2.0 | Needle stucked in pressure plate | Clean and/or replace seal kit | 7.2 |
| doesn't open | Pneumatic cylinder malfunction | Pneumatic cylinder repair by manufacturer | |

8.3 Pneumatic valve 2.0 normally closed


| Error | Cause | Action | Chapter |
|---|---|---|---------|
| Pneumatic valve 2.0 doesn't close properly / com- pletely | Spring in pneumatic cylinder mal- function | Pneumatic cylinder repair by manufacturer | |
| | Debris in valve sea | Clean pneumatic valve 2.0, use HP filter | 7.1 |
| | Valve seat and/or needle cone damaged | Replace seal kit and/or re- place valve body | 7.2 |
| | Pneumatic cylinder malfunction | Pneumatic cylinder repair by manufacturer | |
| | Pneumatic pressure to low | Check pneumatic pressure | |
| Pneumatic | Spring malfunction | Replace seal kit | 7.2 |
| valve 2.0 doesn't open | Needle stucked in pressure plate | Clean and/or replace seal kit | 7.2 |
| | Pneumatic cylinder malfunction | Pneumatic cylinder repair by manufacturer | |

9 Recycling

The pneumatic valve 2.0 is made of metal and plastic. All the metal parts can be recycled. The plastic parts are to be professionally recycled as per local specifications.




10 Appendix B





11 Appendix C






12 Option Sensor Valves NC

Part number: 912170



Assembly: See also drawing 912170 (enclosures of sensor option)



Disassembly in reverse order.

Sensor:

| Serisor. | | |
|---|--------------------------------------|--|
| Basic features | | Electrical data |
| Approval/Conformity | CULUS CE EAC WEEE | Load capacitance max. at Ue Min. operating current Im No-load current Io max., dampe |
| Basic standard | IEC 60947-5-2 | No-load current Io max., undam Operating voltage Ub |
| Display/Operation | | Output resistance Ra Rated insulation voltage Ui |
| Function indicator Power indicator | yes no | Rated operating current le Rated operating voltage Ue DC Rated short circuit current |
| Electrical connection | | Ready delay tv max. |
| Cable diameter D | 3.00 mm | Residual current Ir max. Ripple max. (% of Ue) |
| Cable length L Connection | 0.5 m M8x1-Male, 3-pin | Switching frequency Utilization category |
| Connection type | Cable with connector, 0.50 m, PUR | Voltage drop static max. |
| Polarity reversal protected Protection against device mix-ups | yes yes | Environmental conditi |
| Short-circuit protection | yes | Ambient temperature Contamination scale EN 60068-2-27, Shock EN 60068-2-6, Vibration IP rating |

| Load capacitance max. at Ue | 0.5 μF |
|-----------------------------------|---------------|
| Min. operating current Im | 0 mA |
| No-load current lo max., damped | 12 mA |
| No-load current lo max., undamped | 4 mA |
| Operating voltage Ub | 1030 VDC |
| Output resistance Ra | 33.0 kOhm + D |
| Rated insulation voltage Ui | 75 V DC |
| Rated operating current le | 200 mA |
| Rated operating voltage Ue DC | 24 V |
| Rated short circuit current | 100 A |
| Ready delay tv max. | 10 ms |
| Residual current Ir max. | 80 μΑ |
| Ripple max. (% of Ue) | 15 % |
| Switching frequency | 3000 Hz |
| Utilization category | DC -13 |
| Voltage drop static max. | 2.5 V |
| | |

tions

| Ambient temperature | -2570 °C |
|-------------------------|---------------------------------------|
| Contamination scale | 3 |
| EN 60068-2-27, Shock | Half-sinus, 30 g _n , 11 ms |
| EN 60068-2-6, Vibration | 55 Hz, amplitude 1 mm, 3x30 mir |
| IP rating | IP67 |

Functional safety

MTTF (40 °C) 830 a

Option Sensor Valves NC



| Interface | | |
|--------------------------|------------------------|--|
| Switching output | PNP normally open (NO) | |
| Material | | |
| Housing material | Zinc, Die casting | |
| Material jacket | PUR | |
| Material sensing surface | PBT | |
| Mechanical data | | |
| Dimension | 40 x 8 x 8 mm | |
| Installation | for flush mounting | |
| Size | 8x8 | |

Range/Distance

Assured operating distance Sa 1.6 mm Hysteresis H max. (% of Sr) 15.0 % Rated operating distance Sn 2 mm Real switching distance sr 2 mm 5.0 % Repeat accuracy max. (% of Sr) Switching distance marking Temperature drift max. (% of Sr) 10 % Tolerance Sr ±10 %

Remarks

The sensor is functional again after the overload has been eliminated.

For more information about MTTF and B10d see MTTF / B10d Certificate

Indication of the MTTF- / B10d value does not represent a binding composition and/or life expectancy assurance; these are simply experiential values with no warranty implications. These declared values also do not extend the expiration period for defect claims or affect it in any way.

Connector Drawings



Wiring Diagrams

